





















ASSEMBLY INSTRUCTION

YB008 ARM CHAIR

PARTS LIST

PARTS#	PARTS NAME	DRAWING	QTY	PARTS#	PARTS NAME	DRAWING	QTY
A	FLAT WASHER 5/16"X 3/4"		11	L	PLUG		2
B	LOCK WASHER 5/16"		11	M	Leg		2
C	BOLTS DIA 5/16"X2"		4	N	WOOD SCREW		4
D	BOLTS DIA 5/16"X3"		4	O	LEFT ARM		1
E	BOLTS DIA 5/16"X1-1/2"		2	P	RIGHT ARM		1
F	ALLEN WRENCH 5/16"		1	Q	CUSHION		1
G	BOLTS DIA 1/4"X1-1/2"		2	R	SEAT FRAME		1
H	FLAT WASHER 1/4"		2				
I	LOCK WASHER 1/4"		2	S	CHAIR BACK		1
J	ALLEN WRENCH 1/4"		1				
K	TENON		2	T	BOLTS DIA 5/16"X1-3/4"		1

Note: Do Not tighten bolts until assembly is fully completed.

STEP 1

