[																				
of ea this f CAU Estin	H7	H	H5	H4	H3	H2	H1	No.	HAR	P8	P7	P6	P5	P4	P3 (	P2	P1	No.	PART	
NOTE: PO# is located underneath/ inside of each item. Please be prepared to provide this # should any claim be necessary. CAUTION: Item is heavy assembly should be performed by two people. Estimate Assembly time : 11 minutes	SCREWDRIVERS	ALLEN KEY	SCREWS	FLAT WASHER	SPRING WASHER	BOLT (Ø6X40 MM)	BOLT (Ø6X12 MM)	DESCRIPTION	HARDWARE LIST	SLAT ROLL	CENTER LEGS	CENTER SUPPORT	RAILS	FOOTBOARD	HEADBOARD POST	HEADBOARD POST ( RIGHT )	HEADBOARD PANEL	DESCRIPTION	PARTS LIST	
a prepared to prov be necessary. Any assembly shoul le. a : 11 minutes		7	().	0	Ø	0	0	IMAGE			ļ					/		IMAGE		MONT
id id be	PROVIDE		7	17	17	17	œ	QTY	-	_ <b>_</b>	ω		N	<u> </u>				QTY		EREY
B	<b>P4</b>			LIS C	H2 H2	H3 T	1 dec	H5		C S		P2 (P3)							1	Monterey Queen / Estern K
						H4								H3			, H6 H2	i i i		
							HB		Λ								7 (P)		2	ING / CALI KING BEDS
ASSEMBLY COMPLETED				/ / H5					H3	Ź						، /  بور	<b>***</b>			S Assembly instructions: