

MONTEREY DINING CHAIR

Assembly instructions:

PARTS LIST

No.	DESCRIPTION	IMAGE	QTY
P1	BACK LEG FRAME		1
P2	FRONT LEG (RIGHT)		1
P3	FRONT LEG (LEFT)		1
P4	SEAT CUSHION		1
P5	STRETCHER (RIGHT)		1
P6	STRETCHER (LEFT)		1
P7	METAL BAR		1

HARDWARE LIST

No.	DESCRIPTION	IMAGE	QTY
H1	BOLT (Ø6x40 MM)		1
H2	BOLT (Ø6x70 MM)		8
H3	SCREWS (Ø4x40 MM)		4
H4	SPRING WASHER		9
H5	FLAT WASHER		9
H6	ALLEN KEY		1
H7	SCREWDRIVERS		NOT PROVIDED

NOTE: PO# is located underneath/ inside of each item. Please be prepared to provide this # should any claim be necessary.

Estimate Assembly time : 5 minutes

